


Outdoor Fire Bowl

Model No. AAD1500M



WARNING

FOR YOUR SAFETY:

For Outdoor Use Only
(outside any enclosure)



WARNING

FOR YOUR SAFETY:

1. Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage.
2. Read the installation, operation, and maintenance instructions thoroughly before installing or servicing this equipment.
3. Failure to follow these instructions could result in fire or explosion, which could cause property damage, personal injury, or death.
4. This instruction manual contains important information necessary for the proper assembly and safe use of the appliance.
5. Read and follow all warnings and instructions before assembling and using the appliance.
6. Follow all warnings and instructions when using the appliance.
7. Keep this manual for future reference.



WARNING

FOR YOUR SAFETY:

Do not store or use gasoline or other flammable liquids or vapors in the vicinity of this or any other appliance.



DANGER

Do NOT leave this appliance unattended while it is in operation.

Table of Contents

Important Safeguards	Page 2
Expanded View & Hardware	3
Assembly Instructions.	4
Operating Instructions.	5
Lighting Instructions	5
Extinguishing	5
Cleaning and Care	5
Inspecting	5
Cleaning	5
Storage	5
Product Registration	5
Replacement Parts	5
Limited Warranty	5

THIS INSTRUCTION BOOKLET CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

If you are assembling this unit for someone else, give this manual to him or her to read and save for future reference.



Made from 75% Bagasse
(environmentally friendly sugar
cane pulp by-product)

Important Safeguards

- ⚠ DANGER:** Failure to follow the dangers, warning and cautions in this manual may result in serious bodily injury or death, or in a fire or an explosion causing damage to property.

⚠ WARNING:

 - ⚠ This appliance is for outdoor use only, and shall NOT be used in a building, garage or any other enclosed area.
 - ⚠ Do NOT use this outdoor fire bowl for indoor heating. TOXIC carbon monoxide fumes can accumulate and cause asphyxiation.
 - ⚠ This outdoor fire bowl is NOT for commercial use.
 - ⚠ This outdoor fire bowl is safety certified for use in the United States and Canada only. Do not modify for use in any other location. Modification will result in a safety hazard and will void the warranty.
 - ⚠ This outdoor fire bowl is NOT to be operated by children.
 - ⚠ Do NOT operate, light or use this appliance within ten (10) feet (3.05 m) of walls, structures or buildings.
 - ⚠ Do NOT store or use gasoline or other flammable vapors or liquids within 25 feet (7.62 m) in the vicinity of this or any other appliance.
 - ⚠ Do NOT use in an explosive atmosphere. Keep outdoor fire bowl area clear and free from combustible materials, gasoline and other flammable liquids.
 - ⚠ Apartment Dwellers: Check with management to learn the requirements and fire codes for using an outdoor fire bowl in your apartment complex. If allowed, use outside on the ground floor with a ten (10) foot (3.05 m) clearance from walls or rails. Do not use on or under balconies.
 - ⚠ Always use in accordance with all applicable local, state and national codes. Contact your local fire department for details on outdoor burning.
 - ⚠ When using this outdoor fire bowl, exercise the same precautions you would with any open fire.
 - ⚠ This outdoor fire bowl is NOT to be used in or on boats or recreational vehicles.
 - ⚠ Do NOT use this outdoor fire bowl under any overhead or near any unprotected combustible constructions. Avoid using near or under overhanging trees and shrubs.
 - ⚠ Do NOT use this outdoor fire bowl without reading the entire “owner’s manual.”
 - ⚠ This outdoor fire bowl is for use with torch fuel or lamp oil fuel ONLY.
 - ⚠ Do NOT use gasoline, kerosene, diesel fuel, lighter fluid or alcohol.
 - ⚠ Do NOT alter this outdoor fire bowl in any manner. Any alteration will void your warranty.
 - ⚠ Do NOT use this outdoor fire bowl until it is COMPLETELY assembled and all parts are securely fastened and tightened.
 - ⚠ The use of alcohol, prescription or non-prescription drugs may impair the consumer’s ability to properly assemble and/or safely operate this outdoor fire bowl.
 - ⚠ Do NOT use this outdoor fire bowl near automobiles, trucks, vans or recreational vehicles.
- ⚠ Always use this outdoor fire bowl on a hard, level, non-combustible surface such a concrete, rock or stone. An asphalt or blacktop surface may not be acceptable for this purpose. Do NOT use on wooden decks.
 - ⚠ Do NOT wear flammable or loose clothing when operating this outdoor fire bowl.
 - ⚠ Do NOT use in windy conditions.
 - ⚠ Do NOT lean over this outdoor fire bowl when lighting or while in use.
 - ⚠ Do NOT use this outdoor fire bowl unless spark guards are securely in place.
 - ⚠ Keep all electrical cords away from a hot fire bowl.
 - ⚠ All surfaces of this outdoor fire bowl are hot when in operation. To avoid burns, do NOT touch fire bowl until it has completely cooled unless you are wearing protective gear (potholders, gloves, BBQ mittens, hot pads & etc.). Never touch glass to see if it is hot.
 - ⚠ Do NOT leave a lit outdoor fire bowl unattended, especially around children and pets.
 - ⚠ Do NOT attempt to move or store this outdoor fire bowl until the flame is completely extinguished.
 - ⚠ Do NOT remove ashes or coals until they are completely and fully extinguished and the outdoor fire bowl has completely cooled.
 - ⚠ Avoid breathing smoke from the fire and avoid getting it into your eyes.
 - ⚠ This outdoor fire bowl should be thoroughly inspected and cleaned on a regular basis.
 - ⚠ After a period of storage and/or non-use, check for signs of damage and creosote build-up. Do NOT operate until necessary repairs and/or cleanup are executed.
 - ⚠ Do NOT use oven cleaner or abrasive cleaners as they will damage this product.
 - ⚠ Do NOT clean any part of this outdoor fire bowl in a self cleaning oven as it may damage the finish.
 - ⚠ Use only Blue Rhino Global Sourcing, Inc. factory-authorized parts. The use of any part that is not factory authorized can be dangerous and will void your warranty.
 - ⚠ Use protective gloves when assembling this product.
 - ⚠ Do not throw anything onto the fire when the unit is in operation.
 - ⚠ Do NOT store any combustible materials in the base enclosure.
 - ⚠ Do not force parts together as this can result in personal injury or damage to the product.
 - ⚠ Death, serious injury or damage to property may occur if the above is not followed exactly.

Parts List

1	Fuel Canister Top	58-23-316
2	Fuel Canister	58-23-317
3	Fire Glass Pebbles	58-23-318
4	Glass	58-23-319
5	Bowl	58-23-320
6	Foot (3)	58-23-321

Expanded View

The diagram illustrates the assembly of a fire pit. It features a large bowl (5) at the base, which sits on three feet (6). Inside the bowl, there is a layer of fire glass pebbles (3) and a glass insert (4). A fuel canister (2) is positioned on top of the bowl, and a fuel canister top (1) is placed on the canister. The diagram is a line drawing with numbered callouts for each part.

Assembly Instructions

1

DO NOT RETURN TO PLACE OF PURCHASE.

For assistance, call **1.800.762.1142** toll-free. Please have your Owner’s Manual and model number available for reference.


Assembly Tips:

1. Select an area where you will assemble this product. To protect components, choose a smooth non abrasive surface that’s free of cracks or openings.
2. Spread out all parts.
3. Tighten all hardware connections by hand first. Then, before completing each step, go back and fully tighten all hardware. Be careful not to over-tighten. That could damage surfaces or strip threads.
4. For best results, complete each step in the order presented.

Typical assembly: approximately 20 minutes.

2


Insert Fuel Canister



3


Place Fire Glass Pebbles

Note: Glass rocks should be 0.4-1.2 in. (1-3 cm) long. Approx. 14.5 lbs. (6.6 kg) of glass rocks are needed.



4

Place Glass




Operating Instructions

⚠ WARNING: Before using this outdoor fire bowl, make sure you have read, understand and are following all information provided in the Important Safeguards presented on page 2. Failure to follow those instructions can cause death, serious injury or property damage.

Lighting Instructions

- Carefully pour torch fuel or lamp oil into fuel canister, per fuel container instructions.
- ⚠ CAUTION: Do NOT use gasoline, kerosene, diesel fuel, lighter fluid or alcohol.**
- Remove fuel canister lid and set aside.
Note: fuel canister lid is used for extinguishing and storage
- Using a long lit match or long butane lighter, light the fuel canister wick.



Extinguishing

- Using long handled tongs, carefully place the fuel canister top on the fuel canister.

Cleaning and Care

- ⚠ Caution:**
- All cleaning and maintenance should be done when outdoor fire bowl is cool and with the fuel supply removed.**
 - DO NOT clean any outdoor fire bowl part in a self cleaning oven. The extreme heat will damage the finish.**

Inspecting

This outdoor fire bowl should be inspected on a regular basis to ensure product safety and longer product life.

- ⚠ CAUTION: Do NOT attempt to inspect this outdoor fire bowl until the fire is COMPLETELY out and the fire bowl has cooled completely.**
- Check the handle to make sure it is secure.
 - Check components for any signs of damage or rust.
 - If damage to any component is detected, do NOT operate until repairs are completed.

Cleaning

This outdoor fire bowl should be cleaned on a regular basis to promote safer experiences and longer product life.

Note: After repeated use, a slight discoloration of the finish may occur.

- ⚠ CAUTION: Do NOT attempt to clean this outdoor fire bowl until the fire is COMPLETELY out and the fire bowl has cooled completely.**
- ⚠ CAUTION: Do NOT use oven cleaner or abrasive cleaners as they will damage this product.**
- ⚠ CAUTION: Do NOT clean any part of this outdoor fire bowl in a self-cleaning oven as it may damage the finish.**
- Once the fire is out and outdoor fire bowl is cool to the touch, remove fuel canister and properly dispose of fuel per fuel instructions.
 - Wipe exterior surfaces with a mild dishwashing detergent or baking soda.
 - For stubborn surfaces, use a citrus based degreaser and a nylon scrubbing brush.
 - Rinse clean with water.
 - Remove built-up creosote from components with a chimney cleaning product.

Tip: Keeping the outdoor fire bowl covered when cooled and not in use will help protect it from the elements.

Storage

- ⚠ CAUTION: Do NOT move or store this outdoor fire bowl until the fire is COMPLETELY out and the fire bowl has cooled completely.**
- Once the fire is out, coals are cold and outdoor fire bowl is cool to the touch, remove ashes and properly dispose.
 - Store assembled in a cool, dry location away from children and pets.

Product Registration

For faster warranty service, register your product immediately at www.BlueRhino.com or call 1.800.762.1142.

Replacement Parts

Replacement parts can be found at parts.bluerhino.com or call 1.800.762.1142.

Limited Warranty

Blue Rhino Global Sourcing, Inc. (“Blue Rhino”) warrants to the original retail purchaser of this product, and to no other person, that if this product is assembled, maintained, and operated in accordance with the printed instructions accompanying it, then for a period of one (1) year from the date of purchase, all parts in such product shall be free from defects in material and workmanship. Blue Rhino may require reasonable proof of your date of purchase. Therefore, you should retain your sales slip or invoice. This Limited Warranty shall be limited to the repair or replacement of parts, which prove defective under normal use and service and which Blue Rhino shall determine in its reasonable discretion upon examination to be defective. Before returning any parts, you should contact Blue Rhino’s Customer Service Department using the contact information listed below. If Blue Rhino confirms, after examination, a defect covered by this Limited Warranty in any returned part, and if Blue Rhino approves the claim, Blue Rhino will replace such defective part without charge. If you return defective parts, transportation charges must be prepaid by you. Blue Rhino will return replacement parts to the original retail purchaser, freight or postage prepaid.

This Limited Warranty does not cover any failures or operating difficulties due to accident, abuse, misuse, alteration, misapplication, improper installation or improper maintenance or service by you or any third party, or failure to perform normal and routine maintenance on the product as set out in this owner’s manual. In addition, the Limited Warranty does not cover damage to the finish, such as scratches, dents, discoloration, rust or other weather damage, after purchase.

This Limited Warranty is in lieu of all other express warranties. Blue Rhino disclaims all warranties for products that are purchased from sellers other than authorized retailers or distributors, including the warranty of merchantability or the warranty of fitness for a particular purpose. BLUE RHINO ALSO DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. BLUE RHINO SHALL HAVE NO LIABILITY TO PURCHASER OR ANY THIRD PARTY FOR ANY SPECIAL, INDIRECT, PUNITIVE, INCIDENTAL, OR CONSEQUENTIAL DAMAGES. Blue Rhino further disclaims any implied or express warranty of, and assumes no responsibility for, defects in workmanship caused by third parties.

This Limited Warranty gives the purchaser specific legal rights; a purchaser may have other rights depending upon where he or she lives. Some jurisdictions do not allow the exclusion or limitation of special, incidental or consequential damages, or limitations on how long a warranty lasts, so the above exclusion and limitations may not apply to everyone.

Blue Rhino does not authorize any person or company to assume for it any other obligation or liability in connection with the sale, installation, use, removal, return, or replacement of its equipment, and no such representations are binding on Blue Rhino.

Blue Rhino Global Sourcing, Inc.
Winston-Salem, North Carolina 27105 USA
1.800.762.1142



Instrucciones de operación

▲ ADVERTENCIA: Antes de usar este brasero para exteriores, asegúrese

de haber leído y entendido completamente los importantes

Salvaguardias que se presentan en la página 2. Siga estas

instrucciones completamente pues la falla en seguir las puede causar

daños a la propiedad, serias lesiones y aún la muerte.

Encendido con madera

1. Verifique que únicamente haya quedado una pequeña cantidad de ceniza en el fondo del

platillo.

2. Coloque una capa de leña seca o material

natural para encender el fuego, tal como

Fatwood™, en el centro de la rejilla.

3. Coloque encima una capa de leña seca

cortada en longitudes no mayores de 3/4 del

diámetro del platillo.

▲ PRECAUCIÓN: NO agregue gasolina, keroseno, combustible diesel,

líquido encendedor ni alcohol para reavivar el fuego o aumentarlo.

4. Use una cerilla para encender la leña menuda o el material para encender el fuego.

5. Use guantes resistentes al calor y una herramienta de chimenea para volver a instalar el

resguardo contra chispas una vez que la leña menuda o el material de encendido se hayan

encendido.

Apagado

1. Deje que el fuego se extinga por sí mismo.

2. NO use agua para extinguir el fuego pues esta práctica es peligrosa y puede dañar su

brasero para exteriores.

Limpieza y cuidado

▲ PRECAUCIÓN:

1. Todas las tareas de limpieza y mantenimiento deben llevarse a

cabo cuando el artefacto esté frío (al cabo de unos 45 minutos) y

cuando se haya retirado el suministro de combustible.

2. NO limpie ninguna pieza de este artefacto en un horno de limpieza

automática. El calor extremo dañará el terminado.

Inspección

Este brasero para exteriores debe inspeccionarse a intervalos regulares para asegurar que su

funcionamiento es seguro y prolongar su vida útil.

▲ PRECAUCIÓN: NO intente inspeccionar este brasero para exteriores

antes de que el fuego se haya apagado COMPLETAMENTE y el brasero

se haya enfriado.

1. Examine las manijas para estar seguro de que continúan firmemente instaladas.

2. Inspeccione los componentes para detectar señales de daños u oxidación.

3. Si encuentra que algún componente está dañado, NO opere la unidad antes de haberla

reparada.

Limpieza

Este brasero para exteriores debe limpiarse a intervalos regulares para asegurar su

funcionamiento seguro y prolongar su vida útil.

Nota: Después de repetido uso, la superficie de metal puede descolorarse un poco.

▲ PRECAUCIÓN: NO trate de limpiar este brasero para exteriores antes

de que el fuego se haya extinguido COMPLETAMENTE.

▲ PRECAUCIÓN: NO use productos para limpieza de hornos o limpiadores

abrasivos pues estos dañan la unidad.

▲ PRECAUCIÓN: NO trate de limpiar ningún componente de este brasero

para exteriores en un horno automático de limpieza pues esto daña el

terminado de la unidad.

1. Limpie las superficie exteriores con un detergente suave para el lavado de platos o con

soda de hornear.

2. En superficies donde el detergente o la soda no son suficientes para la limpieza, use un

desengrasante a base de cítricos y un cepillo de nylon para fregar.

3. Enjuague con agua limpia.

4. Remueva la acumulación de creosota de la tapa y los costados del resguardo de ceniza

con un producto de limpieza para chimeneas.

Garantía limitada

Puede encontrar piezas de repuesto en parts.BlueRhino.com o llame al 1.800.762.1142.

Piezas de repuesto

Para beneficiar del servicio de garantía más rápidamente, sírvase registrar su unidad
 inmediatamente visitando nuestro sitio Internet BlueRhino.com/warranty o llamando al
 1.800.762.1142.

Registro del producto

1. Una vez que el fuego se haya apagado, las brazas estén frías y la unidad se sienta
 suficientemente fría al tacto, remueva la ceniza y descártela de manera apropiada.

2. Guarde la unidad armada en una ubicación alejada de niños y mascotas.

▲ PRECAUCIÓN: NO mueva o guarde este brasero para exteriores antes

de que el fuego se haya extinguido COMPLETAMENTE.

Almacenamiento

Sugerencia: Mantener el brasero para exteriores cubierta, una vez que se haya dejado de usar y
 se haya enfriado, ayudará a protegerla contra las inclemencias del tiempo.

Limpieza y cuidado (continuación)

Limpieza

Este brasero para exteriores debe limpiarse a intervalos regulares para asegurar su

funcionamiento seguro y prolongar su vida útil.

Nota: Después de repetido uso, la superficie de metal puede descolorarse un poco.

▲ PRECAUCIÓN: NO trate de limpiar este brasero para exteriores antes

de que el fuego se haya extinguido COMPLETAMENTE.

▲ PRECAUCIÓN: NO use productos para limpieza de hornos o limpiadores

abrasivos pues estos dañan la unidad.

▲ PRECAUCIÓN: NO trate de limpiar ningún componente de este brasero

para exteriores en un horno automático de limpieza pues esto daña el

terminado de la unidad.

1. Limpie las superficie exteriores con un detergente suave para el lavado de platos o con

soda de hornear.

2. En superficies donde el detergente o la soda no son suficientes para la limpieza, use un

desengrasante a base de cítricos y un cepillo de nylon para fregar.

3. Enjuague con agua limpia.

4. Remueva la acumulación de creosota de la tapa y los costados del resguardo de ceniza

con un producto de limpieza para chimeneas.

Para piezas de repuesto, visite
 parts.BlueRhino.com
 1.800.762.1142


Instrucciones de armado

NO DEVUELVA EL PRODUCTO AL LUGAR DE COMPRA
Si necesita ayuda llame, sin cargo, al 1.800.762.1142. Por favor tenga a mano su manual y el número del modelo, para referencia.

Para facilitar el armado:

1. Elija el lugar en el que armará este producto. Para proteger los componentes, elija una superficie lisa, sin fisuras ni hendidjas.
 2. Presente todas las piezas.
 3. Ajuste todas las conexiones de los elementos de ferretería, primero en forma manual. Luego, después de completar cada paso, ajústelos por completo. Tenga cuidado de no ajustar demasiado. Se podrían dañar las superficies o forzar las roscas.
 4. Para obtener mejores resultados, siga todos los pasos en el orden indicado.
- Tiempo de armado estimado 20 minutos.

1




3

Coloque las piedras de vidrio


Nota: Las piedras deben ser de 0,4-1,2 pulg. (1-3 cm) de largo y se necesitan aproximadamente 14,5 lbs (6,6 kg).

4




Coloque el vidrio

2



Inserte el recipiente de combustible

Lista de piezas	
1	Tope del recipiente de combustible
2	Recipiente de combustible
3	Piedras de vidrio
4	Vidrio
5	Cuenco
6	Pata (3)
58-23-316	
58-23-317	
58-23-318	
58-23-319	
58-23-320	
58-23-321	




Salvaguardias importantes

⚠ PELIGRO: El no seguir los avisos de peligro, las advertencias y las precauciones, puede ocasionar un incendio o una explosión, con sus consecuentes daños a la propiedad, lesiones personales y hasta accidentes fatales.

- ⚠ ADVERTENCIA:
- ⚠ Esta unidad es para ser usada al aire libre únicamente y NO debe usarse en un edificio, garaje o cualquier otra área cerrada.
 - ⚠ NO use este brasero para exteriores para calentar el ambiente en interiores. Los gases TÓXICOS de monóxido de carbono pueden acumularse y provocar la asfixia.
 - ⚠ Este brasero para exteriores NO ha sido diseñado para uso comercial.
 - ⚠ Este brasero para exteriores tiene certificación de seguridad para su uso en Estados Unidos y Canadá solamente. No la modifique para utilizarla en otra ubicación. Dicha modificación puede resultar en un riesgo de seguridad e invalidará la garantía.
 - ⚠ El brasero para exteriores NO debe ser usada por los niños.
 - ⚠ NO opere, encienda o use esta unidad a menos de 10 pies (3,05 m) de paredes estructuras o edificaciones.
 - ⚠ NO guarde o use gasolina u otros líquidos o vapores inflamables a menos de 25 pies (7,62 m) de esta unidad o de cualquier otro aparato.
 - ⚠ NO utilice esta unidad en una atmósfera explosiva. Escoga una zona para el brasero para exteriores alejada de materiales combustibles, gasolina y cualquier otro vapor o líquido inflamable.
 - ⚠ Habitantes de apartamentos: consulte con la administración para obtener información sobre los requisitos y códigos de incendio correspondiente al uso de braseros o chimeneas para exteriores en su edificio de departamentos. Si están permitidas, úsela fuera de la vivienda sobre el piso con una separación de diez (10) pies (3,05 m) de la pared o los rieles. No la utilice sobre balcones o debajo de los mismos.
 - ⚠ Observe siempre y use la unidad cumpliendo todos los códigos de incendio aplicables, locales y nacionales. Obtenga de su Departamento de incendios local detalles en cuanto a quemas al aire libre.
 - ⚠ Al usar este brasero para exteriores, observe las mismas precauciones que merece cualquier fuego abierto.
 - ⚠ NO utilice este brasero para exteriores en embarcaciones o vehículos de recreo.
 - ⚠ NO use este brasero para exteriores debajo de aleros o cerca de construcciones combustibles que no estén debidamente protegidas. Evite usar el brasero para exteriores cerca o debajo de árboles y arbustos.
 - ⚠ NO encienda este brasero para exteriores sin haber leído completamente todas las instrucciones de este manual del usuario.
 - ⚠ Este brasero para exteriores debe usarse con combustible de linterna o aceite de lámpara SOLAMENTE.
 - ⚠ NO use gasolina, queroseno, diesel, fluido de encendedor ni alcohol.
 - ⚠ No altere el brasero de ninguna forma. Esto invalidará su garantía.
 - ⚠ NO utilice el brasero para exteriores a menos que esté COMPLETAMENTE montado y que todas las piezas estén bien fijadas y apretadas.
 - ⚠ El uso de bebidas alcohólicas, medicamentos o drogas de farmacia puede afectar la habilidad del usuario para armar debidamente u operar en forma segura este brasero para exteriores.
 - ⚠ NO use este brasero para exteriores cerca de automóviles, camiones,

Brasero para exteriores

Modelo n° AAD1500M




Índice

Salvaguardias importantes	Página 2
Diagrama de explosión y elementos de ferretería	3
Instrucciones de armado	4
Instrucciones de operación	5
Encendido	5
Cocción	5
Apagado del brasero para exteriores	5
Limpieza y cuidado	5
Inspección	5
Limpieza	5
Almacenamiento	5
Registro del producto	5
Garantía limitada	5


ESTE MANUAL DEL USUARIO CONTIENE INFORMACIÓN IMPORTANTE SOBRE LA SEGURIDAD. POR FAVOR, LÉALO Y CONSERVELO PARA FUTURAS CONSULTAS.

Si está montando esta unidad para otra persona, entréguele este manual para futuras consultas.



ADVERTENCIA
PARA SU SEGURIDAD:

Solamente para uso en exteriores
(fuera de cualquier recinto)



ADVERTENCIA
PARA SU SEGURIDAD:

1. Una instalación, ajuste, alteración, reparación o mantenimiento inadecuados pueden causar lesiones o daños a la propiedad.


2. Lea atentamente las instrucciones de instalación, funcionamiento y mantenimiento del equipo antes de instalarlo, ponerlo en marcha o darle servicio.

3. El no seguir estas instrucciones puede ocasionar un incendio o una explosión, con sus consecuentes daños a la propiedad, lesiones personales y hasta accidentes fatales.

4. Este manual de instrucciones contiene información fundamental y necesaria para el armado correcto y uso seguro del artefacto.

5. Lea y respete todas las advertencias e instrucciones antes de armar y utilizar este artefacto.

6. Guarde este manual para consultarlo en el futuro.




ADVERTENCIA
PARA SU SEGURIDAD:

No guarde o use gasolina u otros líquidos o vapores inflamables cerca de esta unidad o de cualquier otro aparato.



PELIGRO

Nunca deje este artefacto encendido sin vigilancia.



Hecho con 75% de bagazo de caña (subproducto de la caña de azúcar respetuoso del medio ambiente)

Fabricado en China para: Blue Rhino Global Sourcing, Inc
Winston-Salem, NC EE.UU. • 1.800.762.1142 • BlueRhino.com
© Blue Rhino Global Sourcing, Inc.
Endless Summer® es una marca registrada de Blue Rhino Global Sourcing, Inc.